

START: 0.04000000 GHz  
STOP: 40.00000000 GHz  
STEP: 0.04000000 GHz

GATE START: -  
GATE STOP: -  
GATE: -  
WINDOW: -

ERROR CORR: 12-TERM  
AVERAGING: 1 PT  
IF BNDWIDTH: 1 KHz

PARAMETER: ---TR1--- ---TR2---  
NORMALIZATION: -S21- -S11-  
SMOOTHING: DATA / MEMORY 0.0 PERCENT 0.0 PERCENT  
DELAY APERTURE: ---PORT1--- ---PORT2---  
REFERENCE PLANE: 0.0000mm 0.0000mm

S21の一目盛り

S11の一目盛り

S21のゼロ点

S11のゼロ点

